

DE

Original-Bedienungsanleitung und Ersatzteilliste
Fugenschneider

GB

Original operating instruction and spare parts list
Floor saw

FR

Originale du mode d'emploi et liste des pièces de rechange
Scie de sol

NL

Origineel Gebruiksaanwijzing en Reservedelenlijst
Vloerenzaagmachine



ZN der Bedienungsanleitung:

5007287-01

Erstellt am:

07 / 2016

Erstellt von:

Sabrina Linden

Datei:

K:\KDV\5007xxx\5007287-Bedienungsanleitung\
5007287-01-Bedienungsanleitung-DE-GB-FR-NL.doc

GÖLZ® GmbH
Dommersbach 51
D-53940 Hellenthal
Telefon: +49 (0) 2482 12 200 / Telefax: +49 (0) 2482 12 222
E-Mail: info@goelz.de / Internet: www.goelz.de

| | |
|---|--|
|  <p>Alle Rechte nach DIN ISO 16016 vorbehalten. Kein Teil dieses Dokuments (Bedienungsanleitung und Ersatzteilliste) darf ohne vorherige schriftliche Genehmigung durch die</p> <p>GÖLZ® GmbH Dommersbach 51 D-53940 Hellenthal</p> <p>reproduziert, angepasst, gesendet, übertragen, auf Datenträger gespeichert oder in eine andere Sprache übersetzt werden.</p> <p>Garantie</p> <p>Wir behalten uns vor, die in diesem Dokument (Bedienungsanleitung und Ersatzteilliste) enthaltenden Informationen jeder Zeit und ohne vorherige Mitteilung zu ändern. GÖLZ® übernimmt keinerlei Gewährleistung für diese Unterlagen. GÖLZ® übernimmt ferner keine Haftung für Fehler in dem vorliegenden Dokument Bedienungsanleitung und Ersatzteilliste) oder für Neben- und Folgeschäden in Zusammenhang mit der Lieferung, Leistung oder Anwendung des Materials.</p> |  <p>Onder voorbehoud van alle rechten volgens DIN ISO 16016. Geen enkel deel van dit document (gebruiksaanwijzing en reservedelenlijst) mag zonder voorafgaande schriftelijke goedkeuring van</p> <p>GÖLZ® GmbH Dommersbach 51 D-53940 Hellenthal</p> <p>gereproduceerd, aangepast, verzonden, overgedragen, op gegevensdragers opgeslaan of in een andere taal vertaald worden.</p> <p>Garantie</p> <p>Wij behouden ons het recht voor om de informatie die u terugvindt in dit document (gebruiksaanwijzing en reservedelenlijst) ten all tijde en zonder voorafgaande mededeling te wijzigen. GÖLZ® verleent geen enkele garantie voor deze documentatie. Voorts neemt GÖLZ® geen enkel aansprakelijkheid op zich voor fouten in onderhavig document (gebruiksaanwijzing en reservedelenlijst) noch voor indirekte of gevolgschade in verband met de levering, prestatie of het gebruik van het materiaal.</p> |
|  <p>All rights reserved according to DIN ISO 16016. No part of this document (instruction manual and spare parts list) may be reproduced, adapted, transmitted, transcribed, stored on a data medium or be translated into another language without prior written approval of</p> <p>GÖLZ® GmbH Dommersbach 51 D-53940 Hellenthal</p> <p>Guarantee</p> <p>We reserve the right to amend any information included in this document (manual instruction and spare parts list) at any time and without prior notice. GÖLZ® assumes no warranty for these documents. GÖLZ® shall not be liable for errors in this document (manual instruction and spare parts list) or for any collateral or consequential damage in connection with shipment, performance or use of the material.</p> |  <p>Tous droits réservés selon DIN ISO 16016. Toute reproduction ou traduction complète ou partielle du présent document (Notice d'utilisation et liste de pièces de rechange) ne peut se faire sans l'autorisation écrite préalable du détenteur des droits, la société:</p> <p>GÖLZ® GmbH Dommersbach 51 D-53940 Hellenthal</p> <p>Garantie</p> <p>Nous nous réservons tous les droits de modification sur les informations contenues dans le présent document (Notice d'utilisation et liste de pièces de rechange). GÖLZ® décline toute responsabilité quant au contenu de la présente notice. GÖLZ® ne peut pas être tenu pour responsable pour d'éventuelles erreurs qui se seraient glissées dans le présent document (Notice d'utilisation et liste de pièces de rechange) ou pour d'éventuels dégâts connexes, ou résultants de la livraison, de l'application ou de l'utilisation.</p> |

| EG-KONFORMITÄTS-ERKLÄRUNG | EC-DECLARATION OF CONFORMITY | DECLARATION DE CONFORMITE DE LA CE | EG-KONFORMITEITS-VERKARING |
|----------------------------------|-------------------------------------|---|-----------------------------------|
| Die Firma | Manufacturer | La Société | De Firma |

GÖLZ® GmbH

Dommersbach 51, D-53940 Hellenthal
Tel.: +49 (0) 2482 12 200 / Fax: +49 (0) 2482 12 222

| | | | |
|---|---|--|--|
| erklärt in alleiniger Verantwortung dass folgende Maschine: | Declare hereby certifies on its sole responsibility that the following product: | déclare sous sa seule responsabilité que le produit suivant: | Komform de bepalingen van de machinerichtlijn verklaart hiermede dat onderstaande machine: |
|---|---|--|--|

FS175

Fugenschneider
Floor saw
Scie de sol
Vloerenzaagmachine

Seriennummer / Serial number / Numéro de série / Seriennummer: _____

| | | | |
|---|--|--|---|
| auf das sich diese Erklärung bezieht, mit folgenden Richtlinien übereinstimmt: 2006/42/EG Sicherheits- und Gesundheitsanforderung 2014/30/EU Elektro-Magnetische Verträglichkeit 97/68/EG i.d.F. 2002/88/EG Abgasrichtlinie 2000/14/EG Geräuschemission | which is explicitly referred to by this declaration meet the following directives: 2006/42/EG Safety and health requirement 2014/30/EU Electromagnetic compatibility 97/68/EG i.d.F. 2002/88/EG Exhaust emission directive 2000/14/EG Noise emission | Qui fait l'objet de la présente déclaration correspond aux directives suivantes: 2006/42/EG Prescriptions sanitaire et sécurité 2014/30/EU Compatibilité électromagnétique 97/68/EG i.d.F. 2002/88/EG Directive de gaz résiduel 2000/14/EG Émission de bruit | Voldoet aan de bepalingen van de machinerichtlijn: 2006/42/EG Zekerheids- en gezondheidsvoorschriften 2014/30/EU Electromagnetische compatibiliteit 97/68/EG i.d.F. 2002/88/EG Betreffende de uitstootgassen 2000/14/EG Geluidsemissies |
|---|--|--|---|

| | | | |
|---|---|---|---|
| mit folgenden Normen übereinstimmt: DIN EN ISO 12100 DIN EN 13862:2010-03 DIN EN 13309:2010-12, DIN EN 61000, DIN EN ISO 3744 Die oben genannte Firma hält Dokumentation als Nachweis der Erfüllung der Sicherheitsziele und die wesentlichen Schutzanforderungen zur Einsicht bereit. | meet the following standards: DIN EN ISO 12100 DIN EN 13862:2010-03 DIN EN 13309:2010-12, DIN EN 61000, DIN EN ISO 3744 Documented evidence conforming to the requirements of the directives is kept available for inspection at the above manufacturer's address. | aux normes suivantes: DIN EN ISO 12100 DIN EN 13862:2010-03 DIN EN 13309:2010-12, DIN EN 61000, DIN EN ISO 3744 Pour faire foi de la conformité et du respect des règles de sécurité, la documentation peut être consultée au siège de la Société susmentionnée. | Conform de norme: DIN EN ISO 12100 DIN EN 13862:2010-03 DIN EN 13309:2010-12, DIN EN 61000, DIN EN ISO 3744 Voormelde firma bewaart documentatie ter inzage als bewijs van de naleving van de veiligheidsregels en de wezenlijke beschermings-eisen. |
|---|---|---|---|



Hellenthal, den 20.07.2016

Geschäftsführer / General Manager /
Président-directeur général / Zaakvoerder
B. Schmitz



| | |
|---|----|
| Preface | 22 |
| Warning signs and symbols | 22 |
| 1. Machine description | 23 |
| 1.1 Intended use-description | 23 |
| 1.2 Technical data..... | 23 |
| 1.3 Shipment and provided accessory..... | 23 |
| 1.4 Main parts | 23 |
| 1.5 Operating elements..... | 24 |
| 1.6 Safety devices..... | 24 |
| 2. Basic safety instructions..... | 24 |
| 2.1 Intended use | 25 |
| 2.2 Operating range | 25 |
| 2.3 Organisational measures | 25 |
| 2.4 Selection and qualification of person | 26 |
| 2.5 Safety instructions governing specific operational phases | 26 |
| 2.6 Special work related to the maintenance and repair of the machine | 27 |
| 2.7 Information about special risks with electrical energy | 27 |
| 2.8 Gas, dust, steam, smoke..... | 28 |
| 2.9 Noise..... | 28 |
| 2.10 Illumination..... | 28 |
| 2.11 Oils, greases and other chemical substances..... | 28 |
| 2.12 Transport..... | 28 |
| 2.13 Store | 29 |
| 3. Preparing for Operation..... | 29 |
| 3.1 Export checking..... | 29 |
| 3.2 Installation..... | 29 |
| 3.3 Blade..... | 29 |
| 3.3.1 Mounting the blade | 30 |
| 3.4 Water supply | 30 |
| 4. Operation..... | 31 |
| 4.1 Before starting the machine..... | 31 |
| 4.2 Starting the machine | 31 |
| 4.3 Cutting operation..... | 32 |
| 4.4 Stop cutting operation | 32 |
| 4.5 Changing the blade | 32 |
| 5. Maintenance | 32 |
| 5.1 General | 32 |
| 5.2 Lubricating chart..... | 33 |
| 5.3 Poly-V belt..... | 33 |
| 5.4 Machine | 33 |
| 5.5 Blade..... | 33 |
| 6. Taper bushes installation instructions..... | 33 |
| 6.1 To assemble | 33 |
| 6.2 Removal..... | 34 |
| 7. Troubleshooting..... | 34 |

| | | |
|-----------|--|-----------|
| 8. | Ersatzteilliste / Spare parts list / Liste de pièces de rechange / Reservedelenlijst | 62 |
| 8.1 | Verwendung der Ersatzteilliste / Using the spare parts list / Utilisation de la liste des pièces de rechange / Gebruik van de lijst van reserveonderdelen | 62 |
| 8.1.1 | Sicherheitsvorschrift / Safety regulation / Consigne de sécurité / Veiligheidsvoorschrift..... | 62 |
| 8.1.3 | Vertriebsstellen / Distribution agencies / Points de Vente / Distributiehandelaars..... | 63 |
| 8.1.2 | Bestellangaben / Ordering information / Indications de commande / Bestellingaanwijdingen .. | 63 |
| 8.2 | Verschleißteile / Wearing parts / Pièces d'usure / Slijtdelen | 65 |
| 9. | Explosionsansichten und Ersatzteillisten - Exploded view and spare parts list - Vues éclatées et liste des pièces de rechange - Explosietekeningen en lijst met reserveonderdelen | 67 |
| 9.1 | Maschine - Machine - Machine - Machine | 67 |
| 9.2 | Fahrwerk - Undercarriage - Châssis - Loopwerk | 69 |
| 9.3 | Schneidkopf kpl. - Cutter head - Tête de sciage avec moteur - Zaagkop..... | 73 |
| 9.4 | Schutzhülle - Blade guard - Capot de protection - Beschermkap Zaagblad..... | 77 |
| 9.5 | Benzinmotor - Engine - Moteur - Motor..... | 79 |
| 9.6 | Aufnahme Führungsstange - Receiving part guiding rod - Support de poignée réglable - Opname geleidingsstang..... | 80 |
| 9.7 | Spindelaufnahme - Spindle holder - Support de relevage - As opname..... | 81 |
| 9.8 | Keilriemenschutzhülle - V-belt guard - V-belt guard Capot de protection - V snaren beschermkap..... | 82 |
| 9.9 | Wassertank - Water Tank - Réservoir d'eau - Watertank..... | 83 |
| 9.10 | Tiefeneinstellung - Pushing bar - Poignée - Diepte instelling | 84 |
| 9.11 | Richtungsanzeiger - Pointer unit - Indicateur de direction - Richtings-aanwijzer | 85 |
| 9.12 | Schubbügel - Pushing bar - Poignée - Schuifbeugel..... | 87 |
| 9.13 | Transportbügel - Lifting eye - Anneau de lavage - Transportbeugel | 88 |



Wear dust protection!



Wear ear muffs!



Never touch!




Important advice!



General danger!



Danger exists to cut oneself!



It is not allowed to move the machine with rotating blade outside of the area in which cutting works have to be performed!

1. Machine description

1.1 Intended use-description

The FS 175 is a floor saw with a cutting depth of up to 165 mm.

Its operating range includes the concrete and asphalt road construction, but mainly for transverse, longitudinal and expansion joints.

Operate the machine only using tools in accordance with the manufacturer's instruction. Using other tools is considered contrary to its designated use. The manufacturer cannot be held liable for any damage resulting from such use. The risk of such misuse lies entirely with the user. Der FS 175 is equipped with a petrol engine Honda GX390 and should be operated with the fuel specified by the manufacturer.



Information: Unconditional observe the owner's manual of the engine manufacturer, which is added!

1.2 Technical data

| | |
|-------------------------------|---|
| Max. cutting depth | 165 mm - 6.5 in. |
| Max. blade-Ø | 450 mm - 17.7 in. |
| Flange size | Ø 100 mm - 3.9 in. |
| Blade shaft size | 25,4 mm - 1 in. |
| Engine | Petrol engine Robin/Subaru or Honda |
| Max. cutting speed with blade | 55 m/s |
| Engine shaft speed | 3600 rpm |

| | |
|---|--|
| Blade shaft speed | 2300 rpm |
| Feed | manual |
| Cutting depth control | Manual with hand wheel |
| Cutting depth gauge | Scale on frame |
| Water supply | 30l Water tank for dry cutting blades |
| V-belt tension | manual |
| Dimensions (L x W x H) | approx. 1200x560x1100 mm - 47.2x22x43.3 in. |
| Weight (without water tank and blade) | approx. 127 kg - 279.4 lbs. |
| Sound power level after DIN ISO 6393 | No load =104 dB(A) Full load =114 dB(A) |
| Sound pressure level after DIN ISO 6393 | No load =88 dB(A) Full load =98 dB(A) |
| Vibration ISO 5349 VDMA 03/2006 | a = 4,5 m/s ² |

1.3 Shipment and provided accessory

- Floor saw FS175 without blade
- Wrench SW 13,17, 30, 32
- Operating instruction and spare parts list floor saw
- Operating instruction engine


For the item number of accessories, please refer to the current catalogue of GÖLZ®

If accessories are used which do not correspond to GÖLZ® specifications, no liability is assumed for any damage resulting hereof.

For details regarding the selection of the right GÖLZ® diamond blades, please refer to the current GÖLZ® catalogue for diamond tools.

1.4 Main parts

- 1.& 2. Frame
3. Cutting depth indicator
4. Poly-V belt guard
5. Blade guard
6. Engine
7. Water tank 30l
8. Hand Wheel
9. Pointer unit
10. Lifting eye
11. Push bow



The base frame (1+2) is the basis for the floor saw. All other components are built on the base frame.

By means of the convenient cutting depth setting (3), the operator can read, at any time, the cutting depth. The rib drive is protected by a poly-V belt guard (4). Thus, the risk of injury is reduced by the rib drive. Furthermore, the rib drive is also protected from impurity during the cutting process.

The blade guard (5) provides the operator and the persons in his working area with optimum protection during the cutting process.

The floor saw FS 175 is equipped with a petrol engine Robin/Subaru of Honda (6). For any other information, please refer to the attached operating manual of the engine manufacturer.

In order to allow dust formation during cutting respectively cooling of the cutter blade, the floor saw is equipped with a pluggable water tank (7). There is also the possibility to cool directly by means of the water supply network respectively to bind the dust.


Controlling the blade depth is by using by the hand wheel (8) which is connected with a trapezoidal spindle.

The route indicator (9) allows precise cuts.

Thanks to the direction indicator the operator can monitor and respect the cutting direction.

With suitable lifting gear can be the floor saw on the attached lifting eye (10) lifted to facilitate transport. The height adjustable push bar (11) allows for non-fatiguing working.

1.5 Operating elements



1. Hand wheel - raising and lowering
2. Depth control

1.6 Safety devices



Danger: During cutting or displacing the machine, all safety devices shown below must be mounted!



2. Basic safety instructions

In this manual the following terms and symbols are used for particular important information:



Note / Important: Contains important information which stands out from the other text!



Attention: Contains instructions which must be strictly observed to prevent damage from the unit and the operator!

Important text passages are highlighted in italics or bold or can be found in a grey highlighted text field.

2.1 Intended use

The machine has been built in accordance with state-of-the-art standards and the recognized safety rules. Nevertheless, its use may constitute a risk to life and limb of the user or of third parties, or cause damage to the machine and to other material property.

The machine must only be used in technical perfect condition in accordance with its designated use and the instructions set out in the operating manual, and only by safety-conscious persons who are fully aware of the risks involved in operating the machine. Any functional disorders, especially those affecting the safety of the machine, should therefore be rectified immediately!

The machine is designed exclusively for cutting in concrete, reinforced concrete, natural stone, cast stone and brickwork. Using the machine for purposes other than mentioned above (such as cutting in wood and so on) is considered contrary to its designated use. The GÖLZ® GmbH cannot be held liable for any damage resulting from such use. The risk of such misuse lies entirely with the user.

Only use gear drives and motors, which are provided by GÖLZ® GmbH. Also attend those operating manuals.

Operating the machine within the limits of its designated use also involves observing the instructions set out in the operating manual and complying with the inspection and maintenance directives.



Attention: Read and observe all the operating instructions which belong to this unit!

2.2 Operating range

Do not modify, add components to or retrofit the unit in a way which could affect its safety and do not use non-official accessories! This is not allowed without prior approval of GÖLZ® GmbH!

2.3 Organisational measures

This operating manual must always be at hand at the place of use of the machine and must be accessible to the person operating the machine!

In addition to this operating manual, all other generally applicable legal and other mandatory regulations relevant to accident prevention and environmental protection must be observed! Such obligations may also comprise the handling of hazardous materials, provisioning and/ or wearing of personal protective equipment, or road traffic regulations.

This operating manual must be supplemented by instructions covering the duties involved in supervising and notifying special organizational features, such as job organization, work flows or the person entrusted with the work. Person entrusted with work on the machine must have read the operating manual prior to taking up work. This applies especially to persons working only occasionally on the machine, e.g. during set-up or maintenance activities.


Check - at least from time to time - whether the personnel is carrying out the work in compliance with the operating manual and paying attention to risks and safety-relevant factors.

For reasons of safety, long hair must be tied back or otherwise secured, garments must be close-fitting and no jewellery - including rings - may be worn.

Severe injury may result from being caught by moving parts of the machine. Personal protective equipment must be used wherever required by the circumstances or by law (e.g. safety glasses, ear protectors, safety boots, suitable safety clothing). Observe the regulations for prevention of accidents! Observe all safety precautions and warnings attached to the machine and always keep them in good and perfectly legible condition.

The personal protection equipment should consist of the following parts:

- 1) Hard hat with ear muff
- 2) Visor or safety glasses
- 3) Dust mask
- 4) Protective gloves
- 5) Safety clothes
- 6) Safety boots



In case event of safety-relevant modifications or changes in the behaviour of the machine, stop the machine immediately and report the malfunction to the competent authority/ person. Do not remove or make inoperative any safety devices the machine is equipped with.

Never make any modifications, additions or conversions which might affect safety without GÖLZ®

GmbH prior approval! This also applies to the installation and adjustment of safety devices as well as to welding and cutting work on supporting structures.

Damaged or worn parts of the product must be replaced immediately. Use genuine spare parts only.

All spare parts and tools must comply with the technical requirements specified by the manufacturer/ distributor. Adhere to the legally prescribed preventive maintenance and inspection intervals or those specified in this operating manual!

Hydraulic hose pipes must be changed within the specified or appropriate intervals, even if no safety-relevant defects are visible.

All maintenance and repair activities must be performed by qualified personnel using suitable tools and other suitable workshop equipment. Observe the fire alarm and fire fighting measures. The personnel must be made familiar with the location and handling of fire extinguishers!

2.4 Selection and qualification of person

Only permitted personnel is allowed to work on and with the machine! The legal minimum age is to be observed!

Only assign trained and instructed personnel! Clearly define the responsibilities of the personnel with regard to operating, setting-up, maintaining and repairing the machine! The **GÖLZ® GmbH** can assist you in training your personnel.

Make sure that only instructed and competent personnel works on the machine. Define the responsibility of the machine operator, also in terms of traffic regulations and enable him to refuse instructions of third parties which breach safety regulations.

Personnel that is to be trained or to be instructed or that is serving a general training is only to be permitted to operate the machine under the supervision of an experienced person.

To operate the machine you must be rested, in good physical condition and mental health. If you have any condition that might be aggravated by strenuous work, check with your doctor before operating with the machine. Do not operate the machine if you are under the influence of any substance (drugs, alcohol) which might impair vision, dexterity or judgment.

Works on electrical, pneumatic, combustion and hydraulic fittings and equipment are only to be carried out by qualified personnel or instructed people being directed and supervised by qualified personnel in compliance with the respective rules!

2.5 Safety instructions governing specific operational phases

Before work

Avoid any operational mode that might be prejudicial to safety!

Before beginning work, familiarize yourself with the surroundings and circumstances of the site, such as

obstacles in the working and travelling area, the soil bearing capacity and any barriers separating the construction site from public roads.

Take the necessary precautions to ensure that the machine is used only when in a safe and reliable state. Operate the machine only if all protective and safety-oriented devices, such as removable safety devices, emergency shut-off equipment, sound-proofing elements and exhausters, are in place and fully functional.

Regard all safety specifications!

Check the machine at least once per working shift for obvious damage and defects. Report any changes (incl. changes in the machine's working behaviour) to the competent organization/ person immediately. If necessary, stop the machine immediately and lock it. Have any defects rectified immediately. At any time, ensure the operator has sufficient view to his working area, in order to have intervention to the working process. Wet cutting is to be accomplished while working. This prevents the appearance of particulate matter and increases the life-time of the diamond tool. During start-up and shut-down procedures always watch the indicators in accordance with the operating instructions!

Before starting or setting the machine in motion, make sure that nobody is at risk. Keep children and unauthorized persons away from the work area.

Noise protection equipment on the unit must be in protective position during operation. Wear the required individual ear protection!

Always keep at a distance from the edges of building pits and slopes. Avoid any operation that might be a risk to machine stability! Keep the work area clean. Cluttered areas and benches invite injuries! Do not operate when you are tired! Watch what you are doing! Risk of stumbling! Cables and hoses must complete rolling up. After assembly do not leave any tools, a wrench for example, on the unit.

Check to see that the tools are removed from the machine before operating! Damaged blades have to be changed immediately. Use only recommended blades from the **GÖLZ® GmbH**.

Control the working area for water-, gas- and electrical lines!



Important: *Wet cutting is to be accomplished while working! This prevents the appearance of particulate matter and increases the life-time of the diamond tool!*

During work

Make sure, that the machine is well fastened before and while cutting!

Never touch rotating parts like blade shaft or blade!

After work

Before leaving the machine always secure it against unauthorized use!

2.6 Special work related to the maintenance and repair of the machine

Observe the adjustment, maintenance and inspection activities and intervals set out in the operating instructions, including information on the replacement of parts and equipment! These activities may be executed by skilled personnel only.

Brief operating personnel before beginning special operations or maintenance work, and appoint a person to supervise the activities.

In any work concerning the operation, conversion or adjustment of the machine and its safety-oriented devices or any work related to maintenance, inspection and repair, always observe the start-up and shut-down procedures described in the operating instructions and the information on maintenance work. Ensure that the maintenance area is adequately secured.

Carry out maintenance and repair work only if the machine is positioned on stable and level ground and has been secured against inadvertent movement and buckling. If the machine is completely shut down for maintenance and repair work, it must be secured against inadvertent starting.

To avoid the risk of accidents, individual parts and large assemblies being moved for replacement purposes should be carefully attached to lifting tackle and secured. Use only suitable and technically perfect lifting gear and suspension systems with adequate lifting capacity. Never work or stand under suspended loads.

The fastening of loads and the instructing of crane operators should be entrusted to experienced persons only. The marshal giving the instructions must be within sight or sound of the operator.

For carrying out overhead assembly work always use specially designed or otherwise safety-oriented ladders and working platforms. Never use machine parts as a climbing aid. Wear safety harness when carrying out maintenance work at greater heights.

Clean the machine, especially connections and threaded unions, of any traces of oil, fuel or preservatives before carrying out maintenance / repair.

Never use aggressive detergents. Use lint-free cleaning rags.

Before cleaning the machine with water, steam jet or detergents, cover or tape up all openings which -for safety and functional reasons - must be protected against water, steam or detergent penetration.

Do not clean the machine with a high-pressure cleaner. The hard water jet can put damage to parts of the machine. After cleaning, remove all covers and tapes applied for that purpose.

After cleaning check the machine for loose connections, chafe marks and damage! Have identified defects repaired immediately!

Always tighten any screwed connections that have been loosened during maintenance and repair.

Any safety devices removed for set-up, maintenance or repair purposes must be refitted and checked immediately upon completion of the maintenance and repair work. Ensure that all consumables and replaced parts are disposed of safely and with minimum environmental impact.

2.7 Information about special risks with electrical energy

Observe the relevant national regulations or standards. Electrical connections must always be kept free from dirt and moisture.

Use only original fuses with the specified rating! Switch off the machine immediately, if trouble occurs in the electric power supply!

If your machine comes into contact with a live wire:

- warn others against approaching and touching the machine
- have the live wire de-energized

When working with the machine, maintain a safe distance from overhead electric lines. If work is to be carried out close to overhead lines, the working equipment must be kept well away from them.

Caution, danger to life!

- Check out the prescribed safety distances.
- Work on the electrical system or equipment may only be carried out by a skilled electrician himself or by specially instructed personnel under the control and supervision of such electrician and in accordance with the applicable engineering rules.
- If provided for in the regulations, the power supply to parts of machines and plants, on which inspection, maintenance and repair work is to be carried out must be cut off.
- Before starting work, check the de-energized parts for the presence of power and ground or short-circuit them in addition to insulating adjacent live parts and elements.

The electrical equipment of machines is to be inspected and checked at regular intervals. Defects such as loose connections or scorched cables must be rectified immediately.

Necessary work on live parts and elements must be carried out only in the presence of a second person who can cut off the power supply in case of danger by actuating the emergency shut-off or main power switch. Secure the working area with a red-and white safety chain and a warning sign. Use insulated tools only.

If mobile electrical equipment, connecting cables and/or extension/ appliance cords with plug connectors are used, ensure that such equipment, cables and cords are checked for correct function at least once every six months by a qualified electrician or - if suitable testing equipment is available - by a properly instructed person.

Protective installations with fault-current protection units used in non-stationary equipment must be checked for correct operation at least once a month by a properly instructed person.

Fault-current and fault-voltage protection units must be checked for correct operation by actuating the testing facility:

- once on every working day in the case of mobile equipment,
- at least once every six months in the case of stationary equipment.

2.8 Gas, dust, steam, smoke

Operate combustion engines only in well-ventilated rooms! Before starting the unit in closed rooms, make sure that the room is sufficiently ventilated and use the exhaust gas hose!

Welding, burning and grinding operations on the machine are only to be carried out if this is explicitly authorized (there is the danger of fire and explosion)!

Before welding, burning and grinding operations clean the machine and its surrounding area from dust and flammable substances and care for sufficient ventilation (danger of explosion)!

When working in confined spaces observe any existing national regulations!

2.9 Noise

During operation sound protection devices on the machine must be in safe position. Wear the prescribed personal ear protection! (UVV 29 § 10, Article 29 of the Accident Prevention regulations).

The use of noise emitting machines may be restricted to certain times by national or local regulations.

2.10 Illumination

The machine is designed for use in daylight! The machine operator / owner must ensure sufficient workplace lighting for non-illuminated work sites!

2.11 Oils, greases and other chemical substances

When handling hydraulic fluids, lubricants, greases or preservatives (referred to hereinafter as fuels and lubricants), the safety regulations which apply to the respective machine are to be observed!

Avoid long contact of the fuels and lubricants with your skin! Careful cleaning of the skin from adhering fuels and lubricants is necessary.

Be careful when handling hot consumables (risk of burning or scalding) particularly at liquid temperatures above 60°C, avoid any skin contact with these liquids! If you get fuels or lubricants in your eyes, rinse them immediately and carefully with potable water. Then consult a doctor.

Remove flown out fuels and lubricants immediately! Therefore use a binder.

Fuels and lubricants must not seep into the soil or into the public sewage system! Fuels and lubricants which can no longer be used are to be collected, properly stored and to be properly disposed of.

The respective regulations and laws for handling fuels and lubricants which are valid in the country of use are to be observed and adhered to. This also applies to the disposal of such fuels and lubricants. To inform yourself turn to the responsible authorities.

2.12 Transport

Use only suitable means of transport and lifting gear of sufficient capacity when loading or transporting the machine! Appoint an experienced instructor for the lifting operation!

Always observe the instructions given in the operating manual when lifting the machine (use only the prescribed lifting eyes for attaching the lifting gear)!

Use only suitable transport vehicles with sufficient load capacity! Secure the load carefully. Use suitable fastening points for securing!

Before loading the machine or parts of it, secure the machine against inadvertent movement! Attach a suitable warning sign!



The blade must be removed for transport. Even in case of a minor change of location, the engine must be stopped!

Before using the machine again, make sure that such protection material or devices are properly removed! Parts which had to be removed for transporting of the machine must be refitted and secured carefully before the machine is used again!

Before setting the machine in motion always check that all accessories are safely stowed.


The recommissioning procedure must be strictly in accordance with the operating instruction! Observe the instructions given in the operating instruction when reassembling and operating the machine.





3.2 Installation

Place the machine on an even, firm and stable ground. Have the working area well lightened. Keep the working area clean, cluttered areas invite injuries. Operating the machine on enclosed premises, make sure that there is sufficient ventilation. Observe the regulations in force at the respective site.



2.13 Store

Store the machine in a dry, high or locked place, out of the reach of children or unauthorized persons. Clean and preserve the machine with corrosion preventive if storing over a longer time like winter time!

Note: Store dismounted blades so, that the blades not exposed to mechanical damages and harmful environmental conditions (UV radiation, temperature, humidity, etc.).




3. Preparing for Operation


3.1 Export checking

Remove the transport packaging and dispose of it in an environmentally responsible way. Check the machine for completeness and intactness. For the scope of delivery, see "Scope of delivery and provided accessory".

Secure the machine against accidental start-up and rolling away.



The machine is not supplied with engine oil.



3.3 Blade




The cutting discs must meet the specification of **GÖLZ® GmbH**. Use the corresponding cutting discs depending on the material to be processed, the machining process and the type of work to be performed! When not used properly, no liability is assumed for damages resulting therefrom.

All used cutting discs must be designed, regarding their maximum admissible cutting speed, for the max. drive speed of the machine. For machines with variable drive speed, use cutting discs which, regarding their maximum admissible cutting speed, correspond to the respective maximum drive speed of the machine. Never use faulty or damaged blades. Check the correct rotation of the blade to the spindle shaft!

Check the blade is well fastened before beginning to operate. Defective cutting discs must be replaced immediately!

Cut off the engine or disconnect the power supply before mounting or changing blade. After mounting, do not leave any tools, such as open-end spanners, on the machine.

Use only blades suitable to the blade acceptance (arbor hole, flanges).



3.3.1 Mounting the blade

Blade mounting:

- Mount the blade to the manufacturer's odds (Observe the min. flange-Ø; use only original screws or nuts).
- Use only blade diameters which are allowed by the manufacturer.


- Secure the blade and outer flange with fixing nut SW30/SW32.
- Fit the blade guard again and secure it with screws.(3)



Danger: It is not allowed to operate the machine without cutting disc blade guard!




Information: Clean all fastening devices of the blade (flanges, thread of the blade shaft, screws and nuts) before mounting the blade!



To dismantle the blade:

- Loose the screw on the back side of blade guard with wrench SW17. (1)
- Remove the blade guard and unscrew the left-hand threaded locking nut and remove the outer clamping flange SW30/SW32. (2-3)
- All clamping surfaces must be clean and undamaged.



To mount the blade:

- Fit the cutting blade. Pay attention to the correct direction of rotation. Observe the direction of rotation arrows on the cutting blade and blade guard. (1-2)
- Mount the outer clamping flange again; (2)

3.4 Water supply



Important: The operation is to be carried out in wet cutting, in order to prevent the occurrence of harmful particulate matter and to increase the lifetime of the cutting tool.



Attention: Tools which are only designed for wet cutting technique, must never be used without water supply! Always make sure that there is enough water supply!

The supply of water at the cut ensures that the tool is cooled, the dust of the material is bound and the cut is rinsed out.



Attention: Use only water for cutting which is free from coarse impurities! Do not use salt water!



Danger: Do not run out of water in the water tank when cutting with wet cutting diamond blades. The segments may crack off and cause injuries to the operator or bystanders!



Cutting with wet-cutting blades:

Connect the detachable water hose with an external water supply. Check the ball valve (2) is closed (ball valve lever in 90°-position to the water flow).

For cutting open the ball valve (2) (ball valve lever in the water flow position).

Cutting with dry-cutting blades:

Fill the water tank with clean water. Check the ball

valve (1) is closed (ball valve lever in 90°-position to the water flow).

For cutting open the ball valve (1) (ball valve lever in the water flow position).

4. Operation



| | |
|--|--|
| | Information: Unconditional observe the owner's manual of the engine manufacturer! |
|--|--|

| | |
|--|--|
| | Danger: Never touch rotating parts like blade shaft or blade while operating! |
|--|--|

4.1 Before starting the machine

Check the machine for safe operating condition.

- All components must be properly mounted.
- The functions of the combustion engine must function properly.
- Do not make any changes on operating elements and safety devices.

The machine may only be operated in safe operating condition.

Lock the push bars so that the machine can be operated in a favorable posture.

If work is carried out where harmful or explosive substances, such as dust, sludge occur, observe the applicable national regulations.

If there is a risk that, during the cutting process, material particles are accelerated outwards, wear safety goggles.



Danger: Demolition parts can cause injuries to the operator while cutting!

When travelling on public roads, ways and places always observe the valid traffic regulations and, if necessary, make sure beforehand that the machine is in a condition compatible with these regulations.

After operating secure the machine against unintentional moving.



Danger: The sound pressure may exceed 85 dB(A)!

Appropriate to the application of the machine it could be necessary to wear further protective equipment.



Danger: Down coming parts at the building site can cause injuries to the operator!

The working area is reserved only for the operator. Keep unauthorized persons out of the working area. Make sure the operator always has well sight to the working area. He always has to intervene in the working process. Never operate the machine without mounted safety devices.

Careless handling can lead to life-threatening injuries caused by the rotating cutting disc. Only operate the machine with fully mounted blade guard.

Nobody is allowed to remain in the working area nor in the area where falling segments of the cutting disc can be accelerated outwards (minimum safety distance 10m). If this safety distance cannot be respected, the danger zone must be closed or be marked by warning signs.


Care for the whereabouts of cooling and rinsing water as well as of cutting sludge.

Cutting sludge must be collected, filtered and disposed of.


4.2 Starting the machine



Danger: As soon as the combustion engine is started, the cutting shaft, respectively the cutting disc, starts rotating too!



During cuts displace the machine only with non-rotating blade (not running engine)!



Completely raise the machine until the brake engages (blade may have no ground contact). Engine switch is in ON position (1).

Emergency switch is unlock (2). Start the engine as described in the engines manual (3).

4.3 Cutting operation



Danger: Operating with too high feed the machine might rise out of cut! In emergency situations cut off the engine as described in the engines manual!



Connect the water supply and slowly lower the machine with the hand wheel (1) till the blade has ground contact. Putting down the machine to the desired cutting depth which is displaying on the cutting depth indicator (2).

Before you lower the machine by means of the hand wheel (1), the mini ball valve is to be opened. Lower the machine to such extent that you reach the desired cutting depth (2).

Pull then the indexing plunger (3) on the control panel, so that it snaps into the catch disk in order to fix the desired cutting depth.

Work with even feed pressure. Too high feed pressure leads to overload of the engine, there is a risk that the machine raises. Too low feed pressure polishes the segments and they become blunt.



Attention: In order to avoid damage to the machine and the cutting disc, please observe the maximum cutting depth!



Note: Do not lower the cutting disc forcibly, this could lead to damage to the cutting disc and to the machine.

4.4 Stop cutting operation

After cutting completely raise the machine and cut off the engine by ON-OFF switch (1) or Emergency switch (2) as described in the engines manual.



Danger: Some parts of the combustion engine become very hot during operation, risk of burns!

4.5 Changing the blade

The blade must be changed if:

- the diamond segments of the blade are completely worn
- the material to be cut changes
- the blade turns irregularly
- the diamond segments are damaged or broken

For fitting a new blade, proceed as described in the chapter "Mounting the blade".

5. Maintenance

5.1 General



Information: Unconditional observe the owner's manual of the engine manufacturer, which is added!



Information: Clean the machine after every operation. Observe local environmental regulations!



Attention: When handling oil, grease and other chemical substances, observe the product-related safety regulations!

For maintenance jobs the machine has to be shut down. For maintenance jobs which must be done while the machine is running, the blade has to be dismounted before beginning the job.

In accordance to the given cycles, the subsequently described maintenance work has to be enforced. Also the wearing part subject to no certain maintenance-intervals has to be checked regularly for wear and to adjust if necessary or to exchange. With I.C. engines, the maintenance work has to be enforced in accordance with the separate maintenance-instruction of the engine manufacturer.

| | | Before starting work | After work | Weekly | Yearly | In the event of a malfunction | If damaged |
|--------------------------------|---|----------------------|------------|--------|--------|-------------------------------|------------|
| Complete machine | Visual inspection (condition, absence of leaks) | X | | | | X | X |
| | clean | | X | | | | |
| Flange and blade holder | clean | | | X | | | |
| Poly-V belt | check | X | | X | | X | X |
| | replace | | | | X | | |
| Water nozzle and feeding hoses | clean | | X | | | | |
| Tools | check | X | | | | X | |
| | clean | | X | | | | |
| | replace | | | | | | X |

5.2 Lubricating chart



Grease the blade shaft bearings after 20 working hours with heat resistance fat. From time to time clean the foot pedal, pointer unit and wheels and grease them with some drops of oil.

5.3 Poly-V belt

Unscrew the screws that fix the motor (4x M10x30, DIN EN ISO 4017) and the screw that fixes the eccentric.

Move the motor forwards by turning the eccentric counter clockwise. In this position the poly-V belt can be replaced easily.

Stress the poly-V belt by turning eccentric clockwise. To fix the motor, screw down the M10x30 screws.



In the case when the eccentric is moved to its farthest position while the belt is still not stressed, remove the eccentric; assemble it in another hole on upper chassis, then start to adjust the belt stress again (1,2,3,4).

5.4 Machine

Clean the machine after each duty and check all functions. Replace all necessary parts that are out of order or worn out immediately.

5.5 Blade

When ending a cutting job - check blade as follows:

Check segments for cracks, break-outs, cracks between segment, deformation and out of round wear.

In case of doubt, send the blade for repair.

6. Taper bushes installation instructions

6.1 To assemble

Clean and de-grease the bore and taper surfaces of the bush and the tapered bore of the pulley. Insert the bush in the pulley hub and line up the holes (half thread holes must line up with half straight holes).

Lightly oil the grub screws or the cap screws and screw them in, do not tighten yet.

Clean and de-grease the shaft. Fit pulley with taper bush on shaft and locate in desired position.


When using a key it should first be fitted in the shaft Keyway. There should be a top clearance between the key and the keyway in the bore.

Using a hexagon socket wrench gradually tighten the grub/cap screws in accordance with the torques as listed in the schedule of screw tightening torques. When the drive has been operating under load for a short period (half to one hour) check and ensure that the screws remain at the appropriate tightening torque. In order to eliminate the ingress of dirt fill all empty holes with grease.

6.2 Removal

Slacken all screws. Depending on the size of the bush remove one or two. After oiling point and thread of grub screws or under head and thread of cap screws, insert them into the jacking off hole(s) in bush.

Tighten screw (s) uniformly and alter neatly until the bush is loose in the hub and pulley is free on the shaft. Remove pulley bush assembly from shaft.



| Bush | Screw tightening torques (Nm) | Screw | |
|------|-------------------------------|----------|-----------|
| | | Quantity | Size |
| 1008 | 5.6 | 2 | 1/4" BSW |
| 1108 | | | |
| 1310 | 20 | 2 | 3/8" BSW |
| 1315 | | | |
| 1210 | 20 | 2 | 3/8" BSW |
| 1215 | | | |
| 1610 | 20 | 2 | 3/8" BSW |
| 1615 | | | |
| 2012 | 31 | 2 | 7/16" BSW |
| 2517 | 48 | 2 | 1/2" BSW |
| 3020 | | | |
| 3030 | 90 | 2 | 5/8" BSW |
| 3535 | 112 | 3 | 1/2" BSW |
| 4040 | 170 | 3 | 5/8" BSW |
| 4545 | 192 | 3 | 3/4" BSW |
| 5050 | 271 | 3 | 7/8" BSW |

7. Troubleshooting



Attention: In the event of changes in the behaviour of the machine during operation, stop the machine immediately and report the malfunction to the competent authority/person!

| Problem | Cause | Remedy |
|------------------------|-------------------------------------|------------------|
| Engine | | |
| Engine does not start! | Fuel tank empty Dirty fuel lines | Fill up Clean |

| Problem | Cause | Remedy |
|---|--|--------------------------------------|
| Engine | | |
| Bad engine performance! | Dirty air cleaner | Clean |
|  Note: For more fault finding refer the operating instruction of the engine manufacturer which is enclosed! | | |
| Lowering | | |
| Machine lowers without actuating the foot pedal! | NOT APPLICABLE | |
| Machine does not fully lower! | NOT APPLICABLE | |
| Cutting | | |
| Machine rises out of cut! | Dull diamond blade | Sharpen or use softer diamond blade |
| | Faulty gas pressure spring | Replace |
| | Feed too high | Reduce feed |
| Non circular abrasion of the diamond blade! | Damaged centring of the blade shaft | Replace blade shaft |
| | Warped blade shaft | Replace |
| | Loose or damaged blade shaft bearings | Tighten or replace |
| Diamond blade jams in the cut! | No free cut because of sideways wear-out of segments | Replace diamond blade |
| | Damaged diamond blade core | Replace diamond blade |
| Abnormal wear-out of segments! | Insufficient water flow | Check hoses for fracture free laying |
| | Wrong type of diamond blade | Choose different diamond blade |
| | Feed too high | Reduce feed |
| | Cutting in loose underground | Reduce cutting depth |
| Abnormal blade wear out at sides of core! | Insufficient water flow | Check hoses for fracture free laying |
| | Cutting in loose underground | Reduce cutting depth |
| Bad cutting performance! | Slippy V-belts | Adjust |
| | Blunt diamond blade | Sharpen or use softer diamond blade |

8. Ersatzteilliste / Spare parts list / Liste de pièces de rechange / Reservedelenlijst

8.1 Verwendung der Ersatzteilliste / Using the spare parts list / Utilisation de la liste des pièces de rechange / Gebruik van de lijst van reserveonderdelen

| | |
|--|--|
| | Die Ersatzteilliste ist keine Montage- oder Demontageanleitung. Diese Ersatzteilliste dient ausschließlich zum einfachen und schnellen finden von Ersatzteilen, die bei den Vertriebsstellen, siehe Kapitel 8.1.3 "Vertriebsstellen", bestellt werden können. |
| | The spare parts list is not a mounting or dismounting instruction. The only purpose of the spare parts list is to easily and quickly find spare parts which can be ordered with distribution agencies, see chapter 8.1.3 "Distribution agencies". |
| | La liste des pièces de rechange n'est pas une notice de montage ou de démontage. Cette liste des pièces de rechange sert exclusivement à trouver rapidement et facilement des pièces de rechange qui peuvent être commandées aux points de vente, voir chapitre 8.1.3 "Points de Vente". |
| | De lijst van reserveonderdelen is geen montage- of demontagehandleiding. De lijst van reserveonderdelen dient uitsluitend voor het eenvoudig en snel terugvinden van reserveonderdelen, die je kan bestellen bij de distributiehandelaars, zie hoofdstuk 8.1.3 "distributiehandelaars". |

8.1.1 Sicherheitsvorschrift / Safety regulation / Consigne de sécurité / Veiligheidsvoorschrift

| | |
|--|--|
| | Gefahr: Montieren oder demontieren von Baugruppen können Risiken hervorrufen, auf die in dieser Ersatzteilliste nicht hingewiesen wird! |
| | Das Verwenden dieser Ersatzteilliste für Montage- oder Demontagezwecke ist nicht erlaubt. Für Montage und Demontagearbeiten sind ausschließlich die entsprechenden Beschreibungen in der Betriebsanleitung zu befolgen. |
| | Gefahr: Nichtbeachten dieser Vorschrift, kann zu Verletzungen führen, die im schlimmsten Fall auch den Tod zu Folge haben könnten! |
| | Danger: Mounting or dismounting assembly groups can give rise to risks which are not mentioned in the spare parts list! |
| | Using this spare parts list for mounting or dismounting purposes is not permitted. For assembly and disassembly work exclusively the corresponding descriptions in this operating manual are to be followed. |
| | Danger: Non-observance of this instruction can result in injury which, in the worst case, can result in death! |
| | Danger: monter ou démonter des modules de construction peuvent être à l'origine de risques qui ne sont pas mentionnés dans cette liste des pièces de rechange! |
| | Pour le montage ou le démontage, l'utilisation de cette liste de pièces de rechange n'est pas autorisée. Pour les travaux de montage et de démontage, suivre exclusivement les descriptions correspondantes indiquées dans le mode d'emploi. |
| | Danger: Le non-respect de cette instruction peut entraîner des blessures qui, dans le pire des cas, peuvent entraîner la mort! |

| | | |
|--|---|---|
| |  | Gevaar: Het monteren en demonteren van onderdelen kan risico's met zich meebrengen, waarnaar niet wordt verwezen in de lijst van reserveonderdelen! |
| |  | Het is niet toegestaan deze lijst van reserveonderdelen voor montage- of demontage doeleinden te gebruiken. Enkel de betreffende beschrijvingen in de gebruiksaanwijzing moeten opgevolgd worden voor montage- en demontagewerkzaamheden. |
| |  | Gevaar: De niet naleving van deze voorschrift kan leiden tot kwetsuren, die in het ergste geval de dood tot gevolg kunnen hebben. |


8.1.3 Vertriebsstellen / Distribution agencies / Points de Vente / Distributiehandelaars

| | |
|---|--|
| Deutschland - Germany - Allemagne - Duitsland GÖLZ® GmbH Dommersbach 51 DE-53940 Hellenthal Tel: +49 (0)2482-12 200 Fax: +49 (0)2482-12 222 E-Mail: info@gelz.de / Internet: www.goelz.de | |
| Österreich - Austria - Autriche - Oostenrijk GÖLZ® Ges.m.b.H Samstraße 52 A-5020 Salzburg Tel: +43 (0) 662 - 43 81 75 Fax: +43 (0) 662 - 43 07 34 E-Mail: info@gelz.at / Internet: www.goelz.at | Frankreich - France - France - Frankrijk GÖLZ® S.A.S. 1, rue de la Mairie F-67370 Berstett Tel: +33 (0)3.88.59.43.00 Fax: +33 (0)3.88.59.47.77 E-Mail: info@golz.fr / Internet: www.golz.fr |
| Großbritannien - Great Britain - Grande-Bretagne - Groot-Brittannië GÖLZ® (UK) Ltd. Unit A5, Springhead, Enterprise Park Northfleet Kent DA11 8HB Tel: +44 1 474321679 Fax: +44 1 474321477 E-Mail: info@gelz.co.uk / Internet: www.goelz.co.uk | Benelux GÖLZ® Benelux Eupener Straße 61 BE-4731 Raeren-Eynatten Tel: +49 (0)2482-12 200 Fax: +49 (0)2482-12 222 E-Mail: benelux@gelz.de / Internet: www.goelz-online.com |
| Australien - Australia - Australie - Australië GOLZ® Pty Ltd. 44 Stanley Street Peakhurst, NSW 2210 Tel: +61 (0) 2 9534 5599 Fax: +61 (0) 2 9534 5588 E-mail: info@golz.com.au / Internet: www.golz.com.au | USA GOLZ® L.L.C. 5860 East Osage Ridge Lane Columbia MO 65203-6018 Tel: +1 573 474 4961 E-Mail: info@golzusa.com / Internet: www.goelz-online.com |

8.1.2 Bestellangaben / Ordering information / Indications de commande / Bestellingaanduidingen

| | | |
|---|---|---|
|  |  | Hinweis: Um Falschlieferungen zu vermeiden sollten vor der Versendung die Angaben in der Bestellung auf Richtigkeit und Vollständigkeit überprüft werden! Lieferadresse vollständig angeben! |
|  |  | Note: In order to avoid wrong deliveries the information the ordering information should be checked for accuracy and completeness before sending it! Completely indicate the delivery address! |

| | | |
|--|--|--|
| | | Notice: Afin d'éviter des livraisons incorrectes, vérifier, avant l'envoi de la livraison, si les indications de commande sont correctes et complètes! Indiquer l'adresse complète de la livraison! |
| | | Gevaar: Om foute leveringen te vermijden dienen voor de verzending de aanduidingen op de bestelling op juistheid en volledigheid te worden gecontroleerd! Het leveradres volledig vermelden! |



| So bekommen Sie schnell und richtig Ihr Ersatzteil | Always indicate | Pour obtenir rapidement les pièces de rechange indiquer | Zo ontvangt u snel uw juiste reserveonderdelen |
|---|--|--|---|
| <ul style="list-style-type: none"> Maschinentyp gemäß Typenschild Baujahr gemäß Typenschild Artikelnummer gemäß Ersatzteilliste Maschinennummer gemäß Typenschild | <ul style="list-style-type: none"> machine type according to nameplate year of manufacture according to nameplate order number according to spare part list serial number according to nameplate | <ul style="list-style-type: none"> type de la machine conforme de plaque d'identification Année de construction selon plaque d'identification Numéro de l'article selon la liste des pièces de rechange numéro de la machine conforme de plaque d'identification | <ul style="list-style-type: none"> Machinetype volgens identificatieplaatje Bouwjaar volgens identificatieplaatje Artikelnummer volgens lijst van reserveonderdelen Machinennummer volgens identificatieplaatje |
| Für Bestellungen, Fragen und Informationen wenden Sie sich bitte an die zuständigen Stellen. | For orders, questions and information, please contact the competent departments. | Pour les commandes, questions et informations, veuillez-vous adresser aux points de ventes correspondants. | Voor bestellingen, vragen of informatie kan u steeds terecht bij de verschillende handelaars. |


8.2 Verschleißteile / Wearing parts / Pièces d'usure / Slijtdelen

| <p>Verschleißteile für die in der Bedienungsanleitung erwähnten Maschinen wie Kernbohrgeräte, Fugenschneider, Wandsägen und Tischkreissägen.</p> <p>Verschleißteile sind Teile, die bei bestimmungsgemäßem Gebrauch der Maschinen einer betriebsbedingten Abnutzung unterliegen. Die Verschleißzeit ist nicht einheitlich definierbar, sie differiert nach der Einsatzintensität. Die Verschleißteile sind gerätespezifisch entsprechend der Betriebsanleitung des Herstellers zu warten, einzustellen und ggf. auszutauschen. Ein betriebsbedingter Verschleiß bedingt keine Mängelansprüche.</p> <p>Verschleißteile sind in der Ersatzteilliste grau unterlegt!</p> <ul style="list-style-type: none"> • Vorschub- und Antriebselemente wie Zahnstangen, Zahnräder, Ritzel, Spindeln, Spindelmuttern, Spindellager, Seile, Ketten, Kettenräder, Riemen • Dichtungen, Kabel, Schläuche, Manschetten, Stecker, Kupplungen und Schalter für Pneumatik, Hydraulik, Wasser, Elektrik, Kraftstoff • Führungselemente wie Führungsleisten, Führungsbuchsen, Führungsschienen, Rollen, Lager, Gleitschutzaflagen • Spannelemente von Schnelltrennsystemen • Spülkopfdichtungen • Gleit- und Wälzlager, die nicht im Ölbad laufen • Wellendichtringe und Dichtelemente • Reib- und Überlastkupplungen, Bremsvorrichtungen • Kohlebürsten, Kollektoren • Leichtlöseringe • Regelpotentiometer und manuelle Schaltelemente • Sicherungen und Leuchten • Hilfs- und Betriebsstoffe • Befestigungselemente wie Dübel, Anker und Schrauben • Bowdenzüge • Lamellen • Membranen • Zündkerzen, Glühkerzen • Teile des Reversierstarters wie Anwerfseil, Anwerklinke, Anwerfrolle, Anwerffeder • Abdichtbürsten, Dichtgummi, Spritzschutzlappen • Filter aller Art • Antriebs-, Umlenkrollen und Bandagen • Seilschlagschutzelemente • Lauf- und Antriebsräder • Wasserpumpen • Schnittguttransportrollen • Bohr-, Trenn- und Schneidwerkzeuge • Energiespeicher | <p>Wearing parts for construction devices mentioned in the operating manual such as drilling and sawing machines.</p> <p>Wearing parts are the parts subject to operation-related (natural) wear during proper use of the device. The wearing time cannot be uniformly defined, and differs according to the intensity of use. The wearing parts must be adjusted, maintained and, if necessary, replaced for the specific device in accordance with the manufacturer's operating manual. Operation-related wear is not a reason for defect claims.</p> <p>Wearing parts of this machine are grey marked in the spare parts list.</p> <ul style="list-style-type: none"> • Feed and drive elements such as toothed racks, gearwheels, pinions, spindles, spindle nuts, spindle bearings, cables, chains, sprockets, belts • Seals, cables, hoses, packings, connectors, couplings and switches for pneumatic, hydraulic, water, electrical and fuel systems • Guide elements such as guide strips, guide bushes, guide rails, rollers, bearings, sliding protection supports • Clamping elements for quick-separating systems • Flushing head seals • Slide and roller bearings that do not run in an oil bath • Shaft oil seals and sealing elements • Friction and safety clutches, braking devices • Carbon brushes, commutators / armatures • Easy-release rings • Control potentiometers and manual switching elements • Securing elements such as plugs, anchors, screws and bolts • Fuses and lamps • Auxiliary and operating materials • Bowden cables • Discs • Diaphragms • Spark plugs, glow plugs • Parts of the reversing starter such as the starting rope, starting pawl, starting roller and starting spring • Sealing brushes, rubber seals, splash protection cloths • Filters of all kinds • Drive rollers, deflection rollers and bandages • Cable anti-twist elements • Running and drive wheels • Water pumps • Cut-material transport rollers • Drilling, parting and cutting tools • Energy storage |
|---|---|

| | |
|---|--|
|  Pièces d'usure définies dans la notice d'utilisation pour les machines telles que carotteuses, scies à sol, scies murales et scies de tables. <p>Les pièces d'usure sont celles définies par une usure normale due à l'utilisation courante de la machine dans les conditions normales d'utilisation. La durée d'usure n'est pas définissable en terme de temps, elle dépend de l'intensité d'utilisation. Les pièces d'usure sont à régler ou changer selon les indications définies dans la notice d'utilisation par le fabricant de la machine. Une usure normale due à l'utilisation de la machine ne peut faire prétendre à une demande de garantie</p> <p>Des pièces d'usure pour cet appareil sont soutenues gris dans le catalogue pièces</p> <ul style="list-style-type: none"> • Éléments d'entraînement, d'avance tels que crémaillères, pignons, vis sans fin écrous pour vis sans fin, roulements de vis, câbles, chaînes, pignons de chaîne, courroies • Joints, câbles électriques, flexibles, manchettes, prises de courant, accouplements et éléments de commande pneumatiques, hydrauliques, pour eau et carburant • Éléments de guidage tels que glissières, douilles de guidage, rails de guidage, galets de guidage, roulements, protections de guidage • Éléments de serrage pour systèmes d'accouplements rapides • Joints de touret d'injection • Roulements à aiguilles et linéaires non en bain d'huile • Joints spi et éléments d'étanchéité • Embrayage de surcharge systèmes de freinage • Charbons et collecteurs • Bagues à desserrage rapide • Potentiomètres et éléments de commandes manuelles • Fusibles et ampoules • Accessoires de fonctionnement • Éléments de fixation tels que chevilles, vis et vis d'ancrage • Sandows • Lamelles • Membranes • Bougies d'allumage et de préchauffage • Pièces du système de démarrage, telles que poignée de démarrage, poulie, ressort • Brosse joint, joints caoutchouc, bavettes anti-éclaboussement • Filtres de tous types • Pouliées d'entraînement ou de renvoi et leur bandage • Éléments anti-flottement de câbles • Roues d'entraînement et de guidage • Pompes à eau • Rouleau de convoyeurs • Outils de carottage et de sciage • Réservoir d'énergie |  Slijtdelen voor de machines vermeld in de handleiding zoals de kernboormachines, voegensnijmachines, wandzagen en tafelcirkelzagen. <p>Slijtdelen zijn die onderdelen die bij een correct gebruik van de machine bedrijfsgerelateerde onderhavig zijn aan slijtage. Slijtagedelen kunnen niet uniform gedefinieerd worden, ze zijn anders afhankelijk van de gebruiksintensiteit. Slijtdelen zijn specifiek voor het toestel overeenkomstig de handleiding van de leverancier te onderhouden, in te stellen en indien nodig te vervangen.</p> <p>Bedrijfsgerelateerde slijtage geeft geen recht op garantie.</p> <p>Slijtonderdelen zijn in de reservedelenlijst in het grijs weergegeven!</p> <ul style="list-style-type: none"> • Voedings- en aandrijvingsonderdelen zoals tandstangen, tandwielen, rondsels, spindels, spindelmoeren, spindellagers, touwen, kettingen, kettingwielen, riemen • Dichtingen, kabels, slangen, manchetten, stekkers, koppelingen en schakelaars voor de pneumatiek, hydrauliek, water, elektriciteit, brandstof • Geleidingselementen zoals geleidingslijsten, geleidingsbussen, rollen, lagers en antislipbeleggingen • Opspanelementen van scheidingssystemen • Dichtingen spoelkoppen • Glij- en rollagers, die niet door een oliebad lopen • As-afdichtringen en dichtingselementen • Wrijvings- en overbelastingskoppeling, remmen • Koolborstels, collectoren • Ring voor snelle (de-)montage • Regelpotentiometer en manuele schakelelementen • Zekeringen en lampen • Hulp- en grondstoffen • Bevestigingselementen zoals wie doppen, ankers en schroeven • Remkabels • Lamellen • Membranen • Ontstekingsbougies, gloeibougies • Onderdelen van de reservestarter zoals startkabel, starrol, startveer • Afdichtingsborstels, dichtingsrubbers, spatlappen • Filters van allerlei aard • Aandrijvings-, omkeerrollen en bandages • Touwslagbeschermingselementen • Loop- en aandrijvingswielen • Waterpompen • Transportrollen materiaal • Boor-, scheidings- en snijwerk具 • Energiebuffer |
|---|--|


9. Explosionsansichten und Ersatzteillisten - Exploded view and spare parts list - Vues éclatées et liste des pièces de rechange - Explosietekeningen en lijst met reserveonderdelen

9.1 Maschine - Machine - Machine - Machine




| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|---|-------------------------------|-------------------------------------|--------------------------------------|---------------------------------|
| 1 | 0282 175 9001 | 1 | | siehe Seite see page regardez à la page zie pagina 69 | Fahrwerk kpl. | Under-carriage complete | Châssis complète | Loopwerk volledig |
| 2 | 0282 175 9014 | 1 | | siehe Seite see page regardez à la page zie pagina 73 | Schneidkopf kpl. | Cutter head complete | Couteau en-tête complète | Zaagkop volledig |
| 3 | 0282 175 9033 | 1 | | siehe Seite see page regardez à la page zie pagina 79 | Motor kpl. | Motor complete | Moteur complète | Motor volledig |
| 4 | 0282 175 9026 | 1 | Ø350 | siehe Seite see page regardez à la page zie pagina 77 | S-Haube kpl. | Blade guard complete | Capot de Protection complète | Bescherm-kap Zaagblad volledig |
| 5 | 0282 175 9037 | 1 | | siehe Seite see page regardez à la page zie pagina 80 | Aufnahme Führungs-stange kpl. | Receiving part guiding rod complete | Support de poignée réglable complète | Opname geleidingsstang volledig |
| 6 | 0282 175 9039 | 1 | | siehe Seite see page regardez à la page zie pagina 81 | Spindelauf-nahme kpl. | Shaft support complete | Fixation de la broche complet | As opname volledig |
| 7 | 0282 175 9044 | 1 | | siehe Seite see page regardez à la page zie pagina 82 | Keilriemen-schutzaube | V-belt guard | Capot de protection | V snaren beschermkap |
| 8 | 0282 170 6160 | 1 | | . siehe Seite see page regardez à la page zie pagina 83 | Wassertank Kpl. | Water Tank complete | Réervoir d'eau complet | Watertank, volledig |
| 9 | 0282 175 9049 | 1 | | siehe Seite see page regardez à la page zie pagina 84 | Tiefeneinstel-lung kpl. | Depth adjustment complete | Système de plongée complet | Diepte instelling volledig |
| 10 | 0282 175 9054 | 1 | | siehe Seite see page regardez à la page zie pagina 85 | Richtungsan-zeigerkpl. | Pointer unit complete | Indicateur de direction complète | Richtings-aanwijzer volledig |
| 11 | 0282 175 9060 | 1 | | siehe Seite see page regardez à la page zie pagina 87 | Schubstange kpl. | Push rod complete | Bielle compilation complète | Trekstang volledig |
| 12 | 0282 175 9062 | 1 | | siehe Seite see page regardez à la page zie pagina 88 | Halterung Transportöse kpl. | Lifting eye holder complete | Crochet de levage complet | Transport-beugel volledig |
| 13 | - | | | | Aufkleber | Sticker | Autocollant | Sticker |

9.2 Fahrwerk - Undercarriage - Châssis - Loopwerk




| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|-----------|---------------|-------------------------|------------------|-------------------|
| - | 0282 175 9001 | 1 | | Pos. 1-43 | Fahrwerk kpl. | Under-carriage complete | Châssis complète | Loopwerk volledig |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|----------------|------------|----------------------------|------|------------------------|----------------------------|-----------------------------------|--------------------|
| 1 | 0282 175 9002 | 1 | | | Fahrgestell | Undercarriage | Châssis | Loopwerk |
| 2 | - | 4 | A8 DIN 127 | | Federring | Spring washer | Rondelle ressort | Veerring |
| 3 | - | 4 | M8x25 DIN EN ISO 4017 | | Schraube | Screw | Vis | Bout |
| 4 | 0282 170 6103 | 2 | Ø200-Ø20x60 | | Hinterrad | Back wheel | Roue arrière | Achterwiel |
| 5 | 0282 130 0017 | 2 | Ø125-Ø15x50 | | Rad | Wheel | Roue | Wiel |
| 6 | 0282 125 6103 | 1 | | | Federriegel | Spring latch | Verrou à ressort | Veerbout |
| 7 | - | 1 | A21 DIN EN ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 8 | - | 1 | A20 DIN 127 | | Federring | Spring washer | Rondelle ressort | Veerring |
| 9 | - | 1 | M20x1,5 DIN EN ISO 8675 | | Mutter | Nut | Écrou | Moer |
| 10 | 0282 175 9003 | 1 | | | Abdeckung | Cover | Coiffe | Afdekking |
| 11 | - | 12 | A4,3 DIN EN ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 12 | - | 12 | A4 DIN 127 | | Federring | Spring washer | Rondelle ressort | Veerring |
| 13 | - | 12 | M4x8 DIN EN ISO 7045 | | Schraube | Screw | Vis | Bout |
| 14 | - | 2 | M14 ISO 7040 | | Mutter | Nut | Écrou | Moer |
| 15 | - | 1 | M10 DIN 934 | | Mutter | Nut | Écrou | Moer |
| 16 | | 1 | M10x45 DIN 933 | | Schraube | Screw | Vis | Bout |
| 17 | -0282 175 9004 | 1 | | | Not-Aus Ring | Emergency stop single ring | Bague de marquage Arrêt d'urgence | Noodstop Ring |
| 18 | 0282 175 9005 | 1 | | | Tiefenanzeiger | Depth finder | Indicateur de la gravité | Diepte-aanduiding |
| 19 | - | 1 | M6x20 DIN EN ISO 4017 | | Schraube | Screw | Vis | Bout |
| 20 | 0282 175 6121 | 1 | M6x16 | | Sterngriffschraube | Star grip screw | Poignée-étoile | Stergreep-schroef |
| 21 | 0282 175 9006 | 2 | | | Werkzeughalter (klein) | Tool holder (small) | Porte-outil | Gereedschap-houder |
| 22 | 0282 175 9007 | 2 | | | Werkzeughalter (groß) | Tool holder (big) | Porte-outil | Gereedschap-houder |
| 23 | 0295 000 2044 | 1 | SW32 DIN 894 | | Maulschlüssel | Wrench | Clé plate | Moersleutel |
| 24 | 0295 000 2031 | 1 | SW30 DIN 894 | | Maulschlüssel | Wrench | Clé plate | Moersleutel |
| 25 | 0295 000 2038 | 1 | SW17 DIN 894 | | Maulschlüssel | Wrench | Clé plate | Moersleutel |
| 26 | 0295 000 2036 | 1 | SW13 DIN 894 | | Maulschlüssel | Wrench | Clé plate | Moersleutel |
| 27 | - | 3 | 6,4 ISO 7093 | | Scheibe | Washer | Rondelle | Ring |
| 28 | 0282 175 9008 | 4 | GN352-30-20-M8 | | Gummipuffer | Bump rubber | Patin | Rubberen buffer |




| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|-----------------------|------------|-------------------------|-------|------------------|----------------|--------------------------------|---------------------|
| 29 | - | 1 | | CE | Aufkleber | Sticker | Autocollant | Sticker |
| 30 | 0282 175 6123 | 2 | 20x23-20 | | Gleitlager | Bush bearing | Roulement coulissant | Glijlager |
| 31 | - | 2 | M20 ISO 7040 | | Mutter | Nut | Écrou | Moer |
| 32 | - | 2 | M5x6 DIN EN ISO 7434 | | Gewindestift | Set screw | Vis sans tête | Schroef-draadpen |
| 33 | 0282 175 9009 | 1 | | FS175 | Aufkleber | Sticker | Autocollant | Sticker |
| 34 | 0282 175 9010 | 1 | | GÖLZ | Aufkleber | Sticker | Autocollant | Sticker |
| 35 | - | 1 | | | Typenschild | Name plate | Plaque signalétique | Typeplaatje |
| 36 | - | 4 | M8 DIN EN ISO 4035 | | Mutter | Nut | Écrou | Moer |
| 37 | 0282 175 9011 | 1 | | | Abdeckung | Cover | Coiffe | Afdekking |
| 38 | 0282 175 9012 | 1 | | | Aufkleber | Sticker | Autocollant | Sticker |
| 39 | - | 1 | NP4-11ZS/1 | | NOT-AUS Schalter | Emergency Stop | Interrupteur d'arrêt d'urgence | Noodstop schakelaar |
| 40 | -0282 175 9013 | 2 | 6 mm | | Schlauchschelle | Hose clamp | Collier | Slangbeugel |
| 41 | - | 2 | D6x16 DIN 7337 | | Blindniete | Blind rivet | Rivet aveugle | Popnagel |
| 42 | - | 1 | M6 ISO 7040 | | Mutter | Nut | Écrou | Moer |
| 43 | - | 4 | Ø2x4 DIN EN ISO 8746 | | Kerbnagel | Grooved pin | Goupille cannelée | Splijtnagel |

9.3 Schneidkopf kpl. - Cutter head - Tête de sciage avec moteur - Zaagkop




| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|-----------|------------------|----------------------|--------------------------|--------------|
| - | 0282 175 9014 | 1 | | Pos. 1-36 | Schneidkopf kpl. | Cutter head complete | Couteau en-tête complète | Zaagkop vol. |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|-----------------------|------|--------------------|----------------------|------------------------------|------------------------|
| 1 | 0282 175 9015 | 1 | | | Grundgestell | Frame | Embase | Basis frame |
| 2 | 0282 175 9016 | 1 | | | Schneidwelle kpl. | Blade shaft complete | Arbre de coupe complète | Zaagas vol. |
| 3 | 0282 175 9017 | 1 | | | Außenflansch | Outer flange | Flasque extérieure | Buitenste flens |
| 4 | 0282 175 9018 | 1 | | | Welle | Shaft | Arbre | As |
| 5 | 0282 175 9019 | 1 | TB12PK97.5 | | Keilrippen-scheibe | V-ripped-pulley | V-déchiré poulie | V-riemschijf |
| 6 | 0282 175 9020 | 1 | 1610-d30 | | Taper - Buchse | Taper - Bushing | Taper - Coussinet | Taper - klembus |
| 7 | 0282 175 9021 | 1 | | | Bremse | Braking plate | Frein | Rem |
| 8 | - | 1 | A8x7x45 DIN 6885 | | Passfeder | Parallel key | Clavette | Vlakspie |
| 9 | 0282 175 6102 | 2 | GFM-2023-16 | | Gleitlager | Slide bearing | Roulement coulissant | Glijlager |
| 10 | - | 2 | A21 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 11 | - | 2 | 5x32 ISO 1234 | | Splint | Split-pin | Goupille | Splint |
| 12 | - | 1 | M10x40 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 13 | - | 4 | A13 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 14 | - | 4 | M10x35 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 15 | 0282 170 0016 | 1 | | | Exzenter | Eccentric | Excentrique | Excenter |
| 16 | 0282 175 9022 | 1 | | | Tiefenanzeigeskala | Skale | Echelle graduée (profondeur) | Schaalverdeling diepte |
| 17 | 0282 175 9023 | 4 | | | Buchse | Bushing | Coussinet | Klembus |
| 18 | 0282 300 0022 | 2 | UCP206-D30(ZX) | | Stehlager | Pedestal bearing | Chaise-palier | Flens lager |
| 19 | | 6 | A10 DIN 127 | | Federring | Spring washer | Rondelle élastique | Veerring |
| 20 | 0282 175 9024 | 1 | | | Gummi Bremse | Braking rubber | Sabot de frein caoutchouc | Rubber rem |
| 21 | - | 3 | Ø6x16 DIN7337 | | Blindniet | Blind rivet | Rivet | Klinknagel |
| 22 | 0282 120 0560 | 1 | 12PK685 | | Poly-V Riemen | V - ripped belt | V - déchiré ceinture | Poly-V Riemen |
| 23 | 0282 175 9013 | 3 | 6 mm | | Schlauchschelle | Hose clamp | Collier | Slangbeugel |
| 24 | 0295 899 0273 | | | | Aufkleber | Sticker | Autocollant | Sticker |
| 25 | - | 4 | M12x40 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 26 | - | 5 | M12 DIN 982 | | Mutter | Nut | Écrou | Moer |
| 27 | - | 1 | M20 x 1,5 LH ISO 8673 | | Mutter | Nut | Écrou | Moer |
| 28 | - | 2 | A6,4 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 29 | - | 6 | A10,5 ISO 7093 | | Scheibe | Washer | Rondelle | Ring |
| 30 | - | 2 | M10x20 ISO 4017 | | Schraube | Screw | Vis | Bout |



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|----------|------------|--------------------|------|-------------|---------------|--------------------|------------|
| 31 | - | 5 | M10 DIN 982 | | Mutter | Nut | Écrou | Moer |
| 32 | - | 2 | A6 DIN 127 | | Federring | Spring washer | Rondelle élastique | Veerring |
| 33 | - | 2 | M6x20 ISO 4762 | | Schraube | Screw | Vis | Bout |
| 34 | - | 1 | M10 DIN 6923 | | Mutter | Nut | Écrou | Moer |
| 35 | - | 1 | M12x65 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 36 | - | 2 | Ø6x10 DIN7337 | | Blindniet | Blind rivet | Rivet | Klinknagel |


9.4 Schutzhaube - Blade guard - Capot de protection - Beschermkap Zaagblad



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|-----------|--------------|-------------|---------------------|---------------------------|
| - | 0282 175 9026 | 1 | | Pos. 1-16 | S-Haube kpl. | Blade guard | Capot de protection | Beschermkap Zaagblad vol. |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|-----------|---------------|------------|-----------------------|-------|-----------------------|-------------------------|------------------------------|----------------------|
| 1 | 0282 175 9027 | 1 | | | S-Haube | Blade guard | Capot de protection | Beschermkap Zaagblad |
| 2 | 0282 175 9028 | 1 | | | Aufnahme Spritzschutz | Splash guard acceptance | Levé bavette anti-projection | Opname sproeier |
| 3 | 0282 175 9029 | 1 | | | Spritzschutz | Splash guard | Bavette antiprojection | Spatrand |
| 4 | - | 2 | A4 DIN 127 | | Federring | Spring washer | Rondelle élastique | Veerring |
| 5 | - | 2 | M4x12 ISO 7045 | | Schraube | Screw | Vis | Bout |
| 6 | - | 1 | A10,5 DIN EN ISO 7093 | | Scheibe | Washer | Rondelle | Ring |
| 7 | - | 1 | M10 DIN982 | | Mutter | Nut | Écrou | Moer |
| 8 | - | 1 | M10x30 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 9 | 0282 175 9030 | 1 | | FS175 | Aufkleber | Sticker | Autocollant | Zelfklever |
| 10 | - | 3 | 15 mm | | Schlauch-schelle | Hose clamp | Collier | Slangbeugel |
| 11 | - | 3 | D6x10 DIN 7337 | | Blindniete | Blind rivet | Rivet aveugle | Popnagel |
| 12 | 0282 130 0527 | 1 | | | Y-Verteiler | Y-Distribution | Y-Distributeur | Verdeler |
| 13 | 0295 899 0314 | 1 | | | Aufkleber | Sticker | Autocollant | Zelfklever |
| 14 | 0282 175 9031 | 1 | | | Aufkleber | Sticker | Autocollant | Zelfklever |
| 15 | 0282 175 9032 | 1 | Ø10.5x30x2 | | Scheibe | Washer | Rondelle | Ring |
| 16 | - | 1 | Ø16,2 | | Schlauch-schelle | Hose clamp | Collier | Slangbeugel |
| ohne Abb. | - | 2 | Ø9x1.5 250 mm | | Schlauch | Hose | Tuyau | Slang |


9.5 Benzинmotor - Engine - Moteur - Motor



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|-----------|-------------|-----------------|-----------------|------------|
| - | 0282 175 9033 | 1 | | Pos. 1-11 | Motor kpl. | Engine complete | Moteur complète | Motor vol. |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|----------------|------------|---------------------------|------|------------------------|-----------------|-------------------------|-----------------|
| 1 | - | 4 | M10x45 ISO 10642 | | Schraube | Screw | Vis | Bout |
| 2 | - | 4 | M10 DIN 6923 | | Mutter | Nut | Écrou | Moer |
| 3 | - | 1 | Honda GX390UT2-SN-C-OH | | Motor | Engine | Moteur | Motor |
| 4 | 0282 175 90034 | 1 | PK12 62.5 Ø25 L61 | | Keilrippen-scheibe | V-ripped-pulley | V-déchiré poulie | V-riemschijf |
| 5 | 0295 899 0224 | 1 | | | Aufkleber | Sticker | Autocollant | Zelfklever |
| 6 | 0282 170 0013 | 1 | | | Motorver-schiebeplatte | Clamping plate | Platine de coulissemant | Klemplaat motor |
| 7 | 0282 170 0235 | 1 | | | Scheibe | Washer | Rondelle | Ring |
| 8 | - | 1 | M8x35 ISO 10642 | | Schraube | Screw | Vis | Bout |
| 9 | 0282 175 9035 | 1 | | | Passfeder | Parallel key | Clavette | Vlakspie |
| 10 | 0282 175 9036 | 1 | | | Schutzplatte | Protctive plate | Rondelle de protection | Beschermplaat |
| 11 | - | 2 | UNF 5/16"-24x3/4" | | Schraube | Screw | Vis | Bout |


9.6 Aufnahme Führungsstange - Receiving part guiding rod - Support de poignée réglable - Opname geleidingsstang



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|----------|------------------------------|-------------------------------------|--------------------------------------|-----------------------------|
| - | 0282 175 9037 | 1 | | Pos. 1-5 | Aufnahme Führungsstange kpl. | Receiving part guiding rod complete | Support de poignée réglable complète | Opname Geleidingsstang vol. |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|----------------------|------|-------------------------|----------------------------|-----------------------------|------------------------|
| 1 | 0282 175 9038 | 1 | | | Aufnahme Führungsstange | Receiving part guiding rod | Support de poignée réglable | Opname Geleidingsstang |
| 2 | - | 8 | A8,4 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 3 | - | 8 | M8x12 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 4 | 0295 002 0022 | 4 | 520511-25.5-22-M8-50 | | Gummipuffer | Bump rubber | Patin | Rubberen buffer |
| 5 | 0282 241 0095 | - | GN602-78-M10-16-SW | | Klemmhebel | Clamping lever | Levier de serrage | Klemhefboom |


9.7 Spindelaufnahme - Spindle holder - Support de relevage - As opname



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|----------|----------------------|-------------------------|------------------------------|--------------------|
| - | 0282 175 9039 | 1 | | Pos. 1-8 | Spindelaufnahme kpl. | Spindle holder complete | Support de relevage complète | As opname volledig |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------------------------|------|---------------------|---------------------|---------------------|-------------------|
| 1 | 0282 175 9040 | 1 | | | Spindelaufnahme | Spindle holder | Support de relevage | As opname |
| 2 | 0282 175 9041 | 1 | D12 | | Augenschraube | Eye screw | Vis à œil | Oogschroef |
| 3 | - | 1 | M12 DIN EN ISO 4032 | | Mutter | Nut | Écrou | Moer |
| 4 | 0282 175 9042 | 1 | Tr20x4 | | Trapezspindel | Trapezoidal spindle | Trapezspindel | Trapezspindel |
| 5 | 0282 175 9043 | 2 | | | Distanzstück | Spacer | Entretoise | Afstandring |
| 6 | - | 4 | A4 DIN 127 | | Federring | Spring washer | Rondelle élastique | Veerring |
| 7 | - | 4 | M4x8 ISO 7045 | | Schraube | Screw | Vis | Bout |
| 8 | - | 1 | M6 DIN71412 | | Kegelschmier-nippel | Grease nipple | Graisseur | Kogel smeernippel |


9.8 Keilriemenschutzhäube - V-belt guard - V-belt guard Capot de protection - V snaren beschermkap



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|----------|----------------------------|-----------------------|---|---------------------------|
| - | 0282 175 9044 | 1 | | Pos. 1-7 | Keilriemenschutzhäube kpl. | V-belt guard complete | V-belt guard Capot de Protection complète | V snaren Beschermkap vol. |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|----------------|------|------------------------------|----------------|------------------------------------|------------------------|
| 1 | 0282 175 9045 | 1 | | | Keilriemenschutzhäube Teil 1 | V-belt guard 1 | V-belt guard Capot de Protection 1 | V snaren beschermkap 1 |
| 2 | 0282 175 9046 | 1 | | | Keilriemenschutzhäube Teil 2 | V-belt guard 2 | V-belt guard Capot de Protection 2 | V snaren beschermkap 2 |
| 3 | - | 3 | M8x20 ISO 4162 | | Schraube | Screw | Vis | Bout |
| 4 | - | 3 | A8 DIN 127 | | Federring | Spring washer | Rondelle élastique | Veerring |
| 5 | - | 3 | M8x12 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 6 | 0282 175 9047 | 1 | | | Aufkleber | Sticker | Autocollant | Zelfklever |
| 7 | - | 3 | M8 ISO 10511 | | Mutter | Nut | Écrou | Moer |


9.9 Wassertank - Water Tank - Réservoir d'eau - Watertank



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|----------|-----------------|------------------|-----------------|---------------------|
| - | 0282 170 6160 | 1 | | Pos. 1-4 | Wassertank kpl. | Water Tank assy. | Réservoir d'eau | Watertank, volledig |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|---------------|----------|---------------------|-------------------------|--------------------------------|---------------------|
| 1 | 0282 170 6162 | 1 | | | Behälterdeckel | Cap | Couvercle du réservoir | Deksel reservoir |
| 2 | 0282 170 6161 | 1 | | Pos. 2.1 | Wassertank | Water Tank | Réservoir d'eau | Watertank |
| | | 1 | GÖLZ | Pos. 2.2 | Haftetikette | Label | Autocollant | Zelfklever |
| 3 | 0282 170 6164 | 1 | | Pos. 3.1 | Anschlussstück | Connector | Raccord | Aansluitstuk |
| | | 1 | 1/4" | Pos. 3.2 | Minikugelhahn | Mini ball valve | Robinet à rotule mini | Minikogelkraan |
| | | 1 | | Pos. 3.3 | Steckanschluss | Quick connector | Accouplement branchement d'eau | Insteek aansluiting |
| | | 1 | | Pos. 3.4 | Steckanschluss | Quick connector | Accouplement branchement d'eau | Insteek aansluiting |
| | | 1 | | Pos. 3.5 | Schelle | Clamp | Collier | Beugel |
| | | 1 | M12 ISO 10511 | Pos. 3.6 | Mutter | Nut | Écrou | Moer |
| | | 2 | A13 ISO 7089 | Pos. 3.7 | Scheibe | Washer | Rondelle | Ring |
| 4 | 0282 170 6163 | 1 | | Pos. 4.1 | Aufnahme Wassertank | Support water reservoir | Support de récipient à eau | Opname watertank |
| | | 2 | Ø20 | Pos. 4.2 | Stopfen | Stopple | Bouchon | Stop |


9.10 Tiefeneinstellung - Pushing bar - Poignée - Diepte instelling



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|-----------|------------------------|---------------------------|----------------------------|----------------------------|
| - | 0282 175 9049 | 1 | | Pos. 1-11 | Tiefeneinstellung kpl. | Depth adjustment complete | Système de plongée complet | Diepte instelling volledig |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------------------|------|----------------|----------------|------------------------|-------------|
| 1 | 0282 175 9050 | 1 | | | Spindel | Shaft | Arbre | Spindel |
| 2 | 0282 175 9051 | 1 | | | Rastscheibe | Locking disc | Rondelle d'arrêt | Rastscheibe |
| 3 | - | 4 | 20x1.2 DIN 471 | | Sicherungsring | Circlip | Circlip | Borgring |
| 4 | 0282 175 9052 | 1 | UCFL204-Ø20 | | Flanschlager | Flange bearing | Coussinet avec flasque | Flenslager |
| 5 | 0282 175 9053 | 1 | Ø200 | | Handrad | Hand wheel | Volant | Handwiel |
| 6 | - | 2 | A6x6x14 DIN 6885 | | Passfeder | Parallel key | Clavette | Vlakspie |
| 7 | - | 1 | A8,4 ISO 7093 | | Scheibe | Washer | Rondelle | Ring |
| 8 | - | 1 | M8x20 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 9 | - | 2 | M12x40 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 10 | - | 4 | A13 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 11 | - | 2 | M12 ISO 10511 | | Mutter | Nut | Écrou | Moer |


9.11 Richtungsanzeiger - Pointer unit - Indicateur de direction - Richtingsaanwijzer



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|------|------|------------------------|-----------------------|----------------------------------|-----------------------------|
| - | 0282 175 9054 | 1 | | | Richtungsanzeiger kpl. | Pointer unit complete | Indicateur de direction complète | Richtingsaanwijzer volledig |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|------------|---------------------------------------|------|--------------------------------|----------------------------|------------------------------|------------------------------|
| 1 | - | 1 | M8 ISO 4032 | | Mutter | Nut | Écrou | Moer |
| 2 | - | 4 | M8 ISO 7040 | | Mutter | Nut | Écrou | Moer |
| 3 | - | 4 | M6x60 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 4 | - | 8 | A6,4 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 5 | 0282 175 9055 | 2 | HRL-3-A-20-PP- ST-M-ZN DIN 3015 | | Befestigungs-schelle | Pipe clamp | Collier de fixation | Bevestigings-klem |
| 6 | 0282 175 9056 | 1 | 20 x 20 | | Stopfen | Stopple | Bouchon | Stop |
| 7 | 0282 120 0084 | 1 | Ø75 x Ø8,2 | | Rad | Wheel | Roue | Wiel |
| 8 | 0282 175 9057 | 1 | | | Gewindestange | Threaded rod | Tige filetée | Draadstang |
| 9 | 0282 175 9058 | 1 | | | Aufnahme Richtungs-anzeiger | Pointer unit | Indicateur de direction | Houder richtingsaanwijzer |
| 10 | - | 4 | M6 DIN EN ISO 7040 | | Mutter | Nut | Écrou | Moer |
| 11 | 0282 175 9059 | 1 | | | Schnittanzeiger | Guidance indicating needle | Indicateur de trait de coupe | Zaag indicator |


9.12 Schubbügel - Pushing bar - Poignée - Schuifbeugel



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|---------------|------|------|-----------------|------------------------|---------------------|----------------------|
| - | 0282 175 9060 | 1 | | | Schubbügel kpl. | Pushing bar complet | Poignée complète | Schuifbeugel vol. |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|---------------|------|------|-------------|-------------|--------------------------|--------------|
| 1 | 0282 175 9061 | 1 | | | Schubbügel | Pushing bar | Poignée | Schuifbeugel |
| 2 | 0282 017 9022 | 2 | | | Griffbezug | Soft grip | Revêtement de poignée | Handvaten |

9.13 Transportbügel - Lifting eye - Anneau de lavage - Transportbeugel



| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|---------------|------|----------|------------------------|-------------------------|---------------------------------|-------------------------------|
| 1 | 0282 175 9062 | 1 | | Pos. 1-5 | Transportbügel kpl. | Lifting eye complete | Anneau de lavage complète | Transport- beugel volledig |

| Pos. | Art.-Nr. | Menge Qty. | Norm | Info | Bezeichnung | Description | Désignation | Benaming |
|------|---------------|---------------|-------------------|------|----------------|---------------|-----------------------|----------------------|
| 1 | 0282 175 9063 | 1 | | | Transportbügel | Lifting eye | Anneau de lavage | Transport- beugel |
| 2 | - | 6 | M8x20 ISO 4017 | | Schraube | Screw | Vis | Bout |
| 3 | - | 2 | A8,4 ISO 7089 | | Scheibe | Washer | Rondelle | Ring |
| 4 | - | 6 | A8 DIN 127 | | Federring | Spring washer | Rondelle élastique | Veerring |
| 5 | - | 4 | A8,4 ISO 7093 | | Scheibe | Washer | Rondelle | Ring |